


# Soportes standard Supporti standard


## COLUMNNA COLONNA

	A	B	L						
EDE85	85	65	500	600	700	800	900	1000	




## COLUMNNA COLONNA

	A	B		
EDEH85	85	400	500	600



## SOPORTE REGULABLE CRUZADO PARA COLUMNNA SUPPORTO PARALLELO PER COLONNA

	A	B	C	D	E	F	G	H	I	L
EIPE60	60	80	100	60	100	140	110	155	5	110
EIPE85	85	80	100	60	100	140	110	155	5	110



## SOPORTE REGULABLE CRUZADO PARA COLUMNNA SUPPORTO INCROCIATO PER COLONNA

	A	B	C	D	E	F	G	H	I	L
ELIE60	60	80	100	60	100	140	110	155	5	110
ELIE85	85	80	100	60	100	140	110	155	5	110

